

Universal adapter cable set

For universal tester CAP-Phase

The adapter cable set is used for contacting mechanically non-standard interfaces which, for example, do not comply with the standard spacing of the sockets or on which there is no socket for the insulating sleeve. Electrically, however, the interface must obey the HR or LRM conditions. For HR interfaces, an HR/LRM adapter must also be used.



Technical Data

General data

| | |
|---------------------|---|
| Article number | 2500063 |
| Product designation | Universal adapter cable set for CAP-Phase |

Dimensions and type of installation

| | |
|----------------|-------|
| Total length L | 10 cm |
|----------------|-------|

Operating conditions

| | |
|-----------------------|----------------|
| Operating temperature | -25°C ... 55°C |
| Storage temperature | -30°C ... 70°C |
| Rated frequency | 50 Hz, 60 Hz |
| Type of interface | LRM, HR |



Kries-Energietechnik GmbH & Co. KG

Sandwiesenstr. 19 | D-71334 Waiblingen

kries.com | service@kries.com | +49 7151 96932 0

© Kries-Energietechnik GmbH & Co. KG | Subject to modifications.

28.10.22

Page 1/1